



Serial

Montage handleiding

Montageanleitung

Instructions de montage

Assembly instructions



RAL 7016

1828

1835



1921










RAL 9006


CI BROSIL









C2 GRESIL

C5 LIGSIL




	RAL 7016	RAL9006
	1. 1233	1232
	2. 1218	1917
	3. 1216	1918
	4. 1726/1727/1892	
	5. 1200/1202	1839/1852
	5a. 1778	
	6. 1222 1225	1840 1893
	7. 1231	
	8. 1230/1229	


	RAL 7016	RAL9006
	12 x	4,8 x 13
	2x	4,8 x 25
	1793	1987




1.




2.




3.




4.




5.




6.




7.



8.




9.




11 x 1726/1727/1892

10.




11.



1216/1918

12.



2X 4,8 x 13